

STARTER



GBSS-***-*****

Manual Motor Starter (MMS) protection on compressor (1ph/3ph DOL/PWS)

MCB protection on condenser fans*

LED indicators - PANEL LIVE / UNIT RUN / UNIT FAULT

MCB protected crankcase/oil separator heater

Universal control circuit connections

Adjustable anti short-cycle protection timer

Oil return solenoid connections

Facility for individual HP switch & Klixon connections on each 3ph fan

Facility for capacity control valve connections on part-wind compressors

***Option to upgrade 3ph fans from MCB to MMS protection**